



## Installation guide

- 1.0 > Open the box remove glass & fixings, place in vertical position only and safely against a wall.
- 2.0 > Install hinges on the glass door, install bracket on the fixed panel glass & Install the bracket onto the top panel, **note: the fittings cannot contact the glass**, the Rubbers and plastic spacers must be fitted to the hinges and brackets to avoid the glass contacting the fittings.
- 3.0 > (**option 1 direct onto shower base**) Make sure that the walls and shower base are plumb.  
(**option 2 direct onto floor tiles**) Make sure that the walls and tiles on the floor are plumb.
- 4.0 > Place fixed panel on to the wall, raise **3 mm** approximately from the Floor level that depends on your wall levels make sure it is plumb from all angles then mark out the bracket holes in correct position with a non staining pen .
- 4.1 > Remove the fixed panel, drill the holes in the correct position and install the fixed panel
- 5.0 > Place door on the wall adjust to correct position raise the door 5 to 10mm from the Floor level ( depending on your floor or shower base and depending if you wish to use the clear seal ) allow 2 to 3mm gap between the door and fixed panel, make sure it is plumb and you are satisfied with the gaps, mark out holes in correct position with Pencil or pen.
- 5.1 > remove the door, drill holes in the correct position and install the door.
- 6.0 > Place top panel in correct position make sure it is level mark out holes with pencil or pen.
- 6.1 > Drill holes in correct position and install.
- 7.0 > Silicone around the fixed panel floor and wall section & Silicone between top panel and fixed panel.

- 8.0 > Clean access silicone using a cloth and (mentholated spirit) or (wax and grease remover)  
It is recommended that you allow 24 hrs for silicone to cure before using the shower.
- 9.0 > **You must retighten and readjust all hinges and fittings after two days of installation to allow for the rubber spacers to compact .**
- 10 > fit plastic strips to lower edge of the door or opening edge of the door ,  
please note the plastic strips are optional according to the individuals taste and image of bathroom

**This diagram is to be used as a guide only it does not include exact measurements as every floor and every wall is different as they all have different tolerances , the installer is responsible to take the glass measurements and calculating the figures prior to drilling and installing the glass , installer is responsible to comply with Australian Standard guidelines for installing glass and handling glass ..**

**If unsure about something email us : [info@buildinggroup.com.au](mailto:info@buildinggroup.com.au)**

## **(SAFETY INFORMATION)**

**IT IS VERY IMPORTANT THAT YOU READ AND UNDERSTAND THE FOLLOWING INSTRUCTION AND SAFETY NOTES BEFORE YOU BEGIN TO INSTALL THIS SHOWER SCREEN.**

- > READ INSTALLATION INSTRUCTIONS
- > ALWAYS CHECK THAT THERE IS NO ELECTRICAL WIRES OR HOSES BEFORE YOU DRILL OR MOUNT ANYTHING.
- > **ALLWAYS WEAR SAFETY GLASSES.**
- > ALLWAYS WEAR GLOVES WHEN HANDLING CHEMICALS, SILCONE OR SUCH.
- > ALLWAYS HAVE ANOTHER PERSON TO HELP YOU IN THE INSTULLATION OF THIS SHOWER, IT IS HEAVY AND CAN CAUSE INJURY.
- > DO NOT DRILL ANY HOLES OR MOUNT ANYTHING UNLESS YOU ARE SURE THEY ARE IN THE CORRECT POSITION.
- > ALWAYS WORK IN A SAFE MANER & COMPLY WITH OHS REQUIRMENTS.
- > DO NOT STAND ON THE SHOWER SCREEN BOX OR ANY OTHER OBJECTS OR FIXINGS IT COULD CAUSE INJURY OR PHYSICAL HARM.
- > DO NOT LEAN ON THE GLASS OR USE IT TO SUPPORT YOU SELF OR ANYONE ELSE.
- > INCORRECT INSTALLATION MAY RESULT IN BREAKING THE SHOWER GLASS AND CAUSE PHYSICAL HARM AND INJURY.
- > DO NOT ALLOW CHILDREN TO USE THE SHOWER ALONE TO PREVENT INJURY.
- > DO NOT ALLOW CHILDREN TO PLAY OR SUCH IN THE SHOWER.
- > ENTER THE SHOWER SLOWLY WITH CARE TO AVOID SLIPPING, SOAP E.T.C... WILL MAKE IT VERY SLIPPERY.
- > DO NOT USE THE SHOWER IF YOU ARE UNDER MEDICATION OR UNDER INFLUENCE OF ALCOHOL OR SUCH THAT MAY CAUSE DROWSINESS OR OTHER RISKS.
- > DO NOT HANG OR PLACE ANYTHING ON ANY PARTS OF THE SHOWER.
- > DO NOT OVER TIGHTEN SCREWS OR PUT UNEVEN PRESSURE ON THE GLASS.
- > DO NOT CLEAN THE SHOWER GLASS OR FIXINGS WITH CHEMICAL SUCH AS ACID, ALKALINE SOLVENTS, SANDPAPER OR OTHER THAT WILL CAUSE DAMAGE.

**This diagram supplied by us are to be used as a guide only , they do not include exact measurements as every floor and every wall is different as they all have different tolerances , the installer is responsible to take the glass measurements and calculating the figures prior to drilling and installing the glass , installer is responsible to comply with Australian Standard guidelines for installing glass and handling glass ..**

**If unsure about something email us : [info@buildinggroup.com.au](mailto:info@buildinggroup.com.au)**