

Step 1 : Clean surface off area where mosaic is to be fitted .

Step 2 : Apply mosaic adhesive to prepared area and align .

Step 3 : Put mosaic onto area adhesive was applied and allow adhesive to dry .

Step 4 : Apply desired colour of supper fine grout onto mosaic .

Step 5 : Allow grout to dry and clean .









